



American Earth Anchors

The best screw you will have in the dirt™

americanearthanchors.com

Installation

9" Penetrator™

PE9 Hex top



3/4"
socket

Install with
impact wrench



PE-T9 T-handle



Turn
by hand



No tools
needed



**Tie-off cable goes onto the anchor
BEFORE the anchor goes into the ground**

1



2

