




American Earth Anchors

americaneearthanchors.com

QUICK REFERENCE

Tie-off cables Specifications


Tie-off cables come in three sizes, to fit specific Penetrators







QUICK REFERENCE

Tie-off cables Installation



Tie-off cables do NOT fit over the Penetrator's flange, so the Penetrator must be put through the tie-off loop either before or during installation:

- (A) Twirl the tie-off cable onto the Penetrator before installation, or
- (B) Install the Penetrator through the tie-off cable



This doubled-over method can be used to create a larger tie-off loop or to wrap around a structural member

Special tie-off cable for PE46Guy

This tie-off cable is a factory-installed option for the PE46Guy Penetrator





Tie-off cables

In the field

Horse shelter




PE18 with tie-off cable up to a fitting on shelter's leg



Frame for fabric building



PE26 with tie-off cable to turnbuckle



Hardpan technique is same as asphalt: Drill 1" pilot hole first

